


Hardware Handbook

Casablanca S-Series
S-3000 / S-6000

MACRO  SYSTEM

Rear Connectors (1)



Tips for connection

Important points in regard to the connection of your Casablanca to a HDMI TV set that is, in turn, connected to other devices.


1. Disconnect from your TV set all antennas, satellite and terrestrial cable feeds, settop boxes, DVD recorders/players and video recorders.
2. Ensure all equipment is disconnected from the power source. Then connect all video and audio cables between your Casablanca and the HDMI TV set. Then connect all video, audio, USB and DV cables from your source camcorder or video player.
3. When all of the above has been completed, you may then connect a network cable to the Casablanca.
4. Lastly, re-connect antennas, satellite cables etc. to the TV set.

The Casablanca should not be powered up until the above sequence has been completed in the correct order.

This approach protects the highly sensitive electronic circuitry from destruction that may result from voltage differentials common in such installations.

Damage caused by nonobservance of the above is not covered by warranty.

Rear Connectors (2)



Inclusions

Casablanca S-3000 or S-6000

- External power supply & cable
- Track ball
- Bogart CD
- Add-on software DVD
- USB adaptor WLAN (only in S-6000)
- DVD Arabesk Manual
- Operating instructions (Bogart SE)
- (this) Hardware Handbook
- HDMI cable
- Firewire cable
- FBAS cable (composite video)
- S VHS video cable
- RCA Audio-cable In stereo
- Registration form
- Software code number sheet
- Regional notes from your supplier

If any of the above items are not included, please notify your supplier.

Please retain the cardboard packaging and styrene inserts, in case the item ever needs to be transported for repair or relocation. This packaging is specifically designed for the safe transportation of your Casablanca.

Replacement packaging is not stocked by Casablanca service providers.

Connections

(1) Mains connection (not illustrated)
Connects the external power supply to the Casablanca. Do not connect to the mains power until the keyed circular mains plug has been correctly inserted and seated.

(2) DVI
Not currently supported .

(3) HDMI
The HDMI port serves the full-digital output of picture and sound to the monitor.

(4) USB (several)
Trackball, ext harddrive, keyboard, AVCHD etc.

(5) Ethernet
Connection to local area network

(6) DV (IN/OUT) - 6 pin.
Firewire (DV) connection for HDV/Mini-DV/ DV-camcorders/players etc.

(7) S/PDIF OUT (optical)
This optical S/PDIF audio output may be connected to a digital audio amplifier.

(8) eSATA
For connection to an external eSATA hard disk.

(9) WLAN (USB)

(10) S video IN (YC)

(11) Video IN (FBAS)

(12) Audio IN (stereo) white=left red=right

Front Panel - (behind flap)



There are additional device connections and the On/Off switch behind the front flap. (lower front, right.)

(A) DV (IN/OUT) - 4 pin.
Firewire connection for the connection of HDV/Mini-DV camcorders etc.

(B) USB x 2
Trackball, ext harddrive, keyboard, AVCHD, thumb drive etc.

(C) Reset (micro)switch

(D) On/Off Switch.